




Thank you for your purchase!

Deutsch
Français
Español
Türkçe



IMPORTANT INFORMATION FOR INSTALLATION:

-  TEMPERATURE of the ambient air and the metal of the vehicle's body during installation must be at least 15°C (60°F). If it is lower - heat the surface and sheets of material with a heat gun
-  Use special Trim Removal Tool to remove the trims to avoid breaking or losing the clips. We also RECOMMEND stocking up on an additional set of clips. If you have difficulty disassembling the panels or the carpet of your vehicle, look up the instructions for cabin disassembly on the Internet for your vehicle's model.
-  The material must only be installed to a clean, dry and grease-free surface! To do this, use products marked "DEGREASER"! Common solvents form an oil layer that prevents the material from adhering to the surface. Therefore, first wipe the surface, make sure that the product (degreaser) does not dissolve the paint and does not leave an oil film on the surface. Only then proceed with the installation.

Useful tips

Examples of installations by model

Calculation of the material needed

Important articles and more

can be found here

kilmat.com

[@kilmat.official](https://www.instagram.com/kilmat.official)

[@KilmatSoundDeadening](https://www.youtube.com/channel/UCkilmatsounddeadening)



If you have any questions, please contact us by email:

info@kilmat.com



While working, use GLOVES to protect your hands. The material has sharp edges!

Apply the material to the ENTIRE surface covering as much as possible of the part you are insulating.

DO NOT cover stiffeners, vents or drains with material! Drainage is needed to remove any condensed moisture to be leaked outside of the vehicle.

ALWAYS roll all the sheets of the material with a ROLLER tool! Roll them down until the embossing on the foil is completely smoothed out. If an "air bubble" was trapped under the material, cut it with a knife, releasing the air, and roll that area again.